

AUTOBADGES

Tint Installation Instructions

Tools Needed:

1. Spray bottle full of water with 2-3 drops of dish soap
2. Plastic application card (squeegee; included)
3. Paper Towels



Installation Procedure:

1. Clean lens thoroughly. (We recommend aligning proper overlays to each lens)



2. Peel Backing from film (prevent film from touching any foreign surfaces). Spray soapy water solution on both the taillight and tint overlay.



3. Align and apply film to one side or center of the light



4. Using the provided plastic application card covered in a paper towel press down/sweet the remainder of the film across the light.
5. If large bubbles are present or film is misaligned, peel up the film to that area and apply again.



6. After each lens repeat the process until light is complete.



*NOTE: 3rd and furthest lens is the most difficult as it does curve. As one half of that tint settles you will be able to push out all the bubbles...but be patient and careful for a perfect finish!

FINISH OF BLACKOUT TINTS IN SUNLIGHT:



FINISH OF 50% SMOKED TINT IN SUNLIGHT:





Comparison of 50% Smoked (top) vs. Blackout Tint (bottom)



SETTING:

Small air bubbles and creases/ripples will disappear over time as film settles and is warmed. Minor scratches will also disappear over time and after film maintenance by waxing.

MAINTENANCE CARE:

The film can be washed with soap and water just as you use on your car's finish. Light scrubbing is ok as well as a mild solvent if needed. Condition the films with a good carnauba wax.

For show, competition and off-road use only. Please check with your local law enforcement about the legality of these lenses.